

**Maintenance of Industrial
Control Equipment**



ATTENTION: Servicing energized Industrial Control Equipment can be hazardous. Severe injury or death can result from electrical shock, burn, or unintended actuation of controlled equipment. Recommended practice is to disconnect and lockout control equipment from power sources, and release stored energy, if present. Refer to National Fire Protection Association Standard No. NFPA70E, Part II and (as applicable) OSHA rules for Control of Hazardous Energy Sources (Lockout-Tagout) and OSHA Electrical Safety Related Work Practices for safety related work practices, including procedural requirements for lockout-tagout, and appropriate work practices, personnel qualifications and training requirements where it is not feasible to de-energize and lockout or tagout electric circuits and equipment before working on or near exposed circuit parts.

Periodic Inspection

Industrial control equipment should be inspected periodically. Inspection intervals should be based on environmental and operating conditions and adjusted as indicated by experience. An initial inspection within 3 to 4 months after installation is suggested. See National Electrical Manufacturers Association (NEMA) Standard No. ICS 1.3, Preventive Maintenance of Industrial Control and Systems Equipment, for general guidelines for setting-up a periodic maintenance program. Some specific guidelines for Sprecher + Schuh products are listed below.

Contamination

If inspection reveals that dust, dirt, moisture or other contamination has reached the control equipment, the cause must be eliminated. This could indicate an incorrectly selected or ineffective enclosure, unsealed enclosure openings (conduit or other) or incorrect operating procedures. Replace any improperly selected enclosure with one that is suitable for the environmental conditions - refer to NEMA Standard No. 250, Enclosures for Electrical Equipment for enclosure type descriptions and test criteria. Replace any damaged or embrittled elastomer seals and repair or replace any other damaged or malfunctioning parts (e.g., hinges, fasteners, etc.). Dirty, wet or contaminated control devices must be replaced unless they can be cleaned effectively by vacuuming or wiping. **Compressed air is not recommended for cleaning because it may displace dirt, dust, or debris into other parts or equipment, or damage delicate parts.**

Cooling Devices

Inspect blowers and fans used for forced air cooling. Replace any that have bent, chipped, or missing blades, or if the shaft does not turn freely. Apply power momentarily to check operation. If unit does not operate, check and replace wiring, fuse, or blower or fan motor as appropriate. Clean or change air filters as recommended in the product manual. Also, clean fins of heat exchangers so convection cooling is not impaired.

Hazardous Location Enclosures



ATTENTION: Explosion hazard. Always disconnect power before opening enclosures in hazardous locations. Close and secure such enclosures before reapplying power.

NEMA Type 7 and 9 enclosures require careful handling so machined flanges do not get damaged. For removable covers, remove the cover and set aside with machined surface up. For hinged covers, open the cover fully and restrain in the full open position if necessary. Clean and examine the flanges on both the body and cover before reassembly. If there are scratches, nicks, grooves or rust on the mating surfaces, replace the body or cover as necessary. Examine all bolts and replace any that have damaged threads. Also check mating threads for damage and replace enclosure if necessary. Covers and bodies of some enclosures are manufactured as matched sets (not interchangeable). The manufacturer should be consulted before replacing a cover or body unless it is specified by the manufacturer as interchangeable.

Operating Mechanisms

Check for proper functioning and freedom from sticking or binding. Replace any broken, deformed or badly worn parts or assemblies according to individual product renewal parts lists. Check for and retighten securely any loose fasteners. Lubricate if specified in individual product instructions.

NOTE: Sprecher + Schuh magnetic starters, contactors and relays are designed to operate without lubrication - do not lubricate these devices because oil or grease on the pole faces (mating surfaces) of the operating magnet may cause the device to stick in the "ON" mode. Some parts of other devices are factory lubricated - if lubrication during use or maintenance of these devices is needed, it will be specified in their individual instructions. If in doubt, consult your nearest Sprecher + Schuh Sales Representative or Technical Support.

Contacts

Check contacts for excessive wear and dirt accumulations. Vacuum or wipe contacts with a soft cloth, if necessary, to remove dirt. Contacts are not harmed by discoloration and slight pitting. Contacts should never be filed, as dressing only shortens contact life. Contact spray cleaners should not be used as their residues on magnet pole faces or in operating mechanisms may cause sticking, and on contacts can interfere with electrical continuity. Contacts should only be replaced after silver has become badly worn. Always replace contacts in complete sets to avoid misalignment and uneven contact pressure.

Terminals

Loose connections in power circuits can cause overheating that can lead to equipment malfunction or failure. Loose connections in control circuits can cause control malfunctions. Loose bonding or grounding connections can increase hazards of electrical shock and contribute to electromagnetic interference (EMI). Check the tightness of all terminals and bus bar connections and tighten securely any loose connections. Replace any parts or wiring damaged by overheating, and any broken wires or bonding straps.

Arc Chutes

Check for cracks, breaks, or deep erosion. Arc hoods and arc chutes should be replaced if damaged or deeply eroded.

Coils

If a coil exhibits evidence of overheating (cracked, melted or burned insulation), it must be replaced. In that event, check for and correct overvoltage or undervoltage conditions, which can cause coil failure. Be sure to clean any residues of melted coil insulation from other parts of the device or replace such parts.

Pilot Lights

Replace any burned out lamps or damaged lenses.

Solid State Devices



ATTENTION: Use of other than factory recommended test equipment for solid state controls may result in damage to the control or test equipment or unintended actuation of the controlled equipment. Refer to paragraph titled **HIGH VOLTAGE TESTING**.

Solid state devices require little more than a periodic visual inspection. Discolored, charred or burned components may indicate the need to replace the component or circuit board. Necessary replacements should be made only at the PC board or plug-in component level. Printed circuit boards should be inspected to determine whether they are properly seated in the edge board connectors. Board locking tabs should also be in place. Solid state devices must also be protected from contamination, and cooling provisions must be maintained - refer to paragraphs titled **CONTAMINATION** and **COOLING DEVICES** on previous page. Solvents should not be used on printed circuit boards.

High Voltage Testing

High voltage insulation resistance (IR) and dielectric withstanding voltage (DWV) tests should not be used to check solid state control equipment. When measuring IR or DWV of electrical equipment such as transformers or motors, a solid state device used for control or monitoring must be disconnected before performing the test. Even though no damage is readily apparent after an IR or DWV test, the solid state devices are degraded and repeated application of high voltage can lead to failure.

Locking and Interlocking Devices

Check these devices for proper working condition and capability of performing their intended functions. Make any necessary replacements only with Sprecher + Schuh renewal parts or kits. Adjust or repair only in accordance with Sprecher + Schuh instructions.

Maintenance After a Fault Condition

Opening of the short circuit protective device (such as fuses or circuit breakers) in a properly coordinated motor branch circuit is an indication of a fault condition in excess of operating overload. Such conditions can cause damage to control equipment. Before restoring power, the fault condition must be corrected, and any necessary repairs or replacements must be made to restore the control equipment to good working order. Refer to NEMA Standards Publication No. ICS-2, Part ICS2-302 for procedures.

Replacements

Use only replacement parts and devices recommended by Sprecher + Schuh to maintain the integrity of the equipment. Make sure the parts are properly matched to the model, series and revision level of the equipment.

Final Check Out

After maintenance or repair of industrial controls, always test the control system for proper functioning under controlled conditions that avoid hazards in the event of a control malfunction.

For additional information, refer to NEMA ICS 1.3, **PREVENTIVE MAINTENANCE OF INDUSTRIAL CONTROL AND SYSTEMS EQUIPMENT**, published by the National Electrical Manufacturers Association, and NFPA70B, **ELECTRICAL EQUIPMENT MAINTENANCE**, published by the National Fire Protection Association.

sprecher+ schuh

Sprecher + Schuh

15910 International Plaza Dr., Houston, TX 77032

Customer Service: (877) 721-5913; Fax: (800) 739-7370

www.sprecherschuh.com