


# PCS (108-135A) and PF\_ (5-135A) Series B Fan Replacement

(Cat PCV-234, PFV-0085)



**ATTENTION:** To prevent electrical shock, disconnect from power source before installing or servicing.  
Install in suitable enclosure. Keep free from contaminants.

## Fan Removal



## Fan Installation

