




WARNING

To prevent electrical shock, disconnect from power source before installing or servicing.
Protective modules must **NOT** be mounted on the load side when used with controllers that use an inside-the-delta motor connection. Installing them with an inside-the-delta motor connection will result in immediate damage to the protective module.

Installation


1



41053-180-01
DIR 41053-180 (Version 02)
Printed in Korea

Installation (Cont'd)

2



41053-180-01
DIR 41053-180 (Version 02)
Printed in Korea

-01	TWO SIDES PRINTED BODY STOCK WHITE BODY INK BLACK	5" W x 4" H	2-1/2" W x 2" H
MATERIAL MASTER	MATERIAL	FLAT	FOLD
		SIZE	
<p align="center">Rockwell Automation</p>		CONFIDENTIAL AND PROPRIETARY INFORMATION. THIS DOCUMENT CONTAINS CONFIDENTIAL AND PROPRIETARY INFORMATION OF ROCKWELL AUTOMATION, INC. AND MAY NOT BE USED, COPIED OR DISCLOSED TO OTHERS, EXCEPT WITH THE AUTHORIZED WRITTEN PERMISSION OF ROCKWELL AUTOMATION, INC.	
		Sheet	1
SPRECHER+SCHUH PCS MOV PROTECTIVE MODULE INSTALLATION INSTRUCTION SHEET		Size	Ver
Dr. G. Ushakow	Date 03-15-11	B	41053-180
			02