


# Busbar For Bulletin L8-... (L8-A...)




**WARNING**

To prevent electrical shock, disconnect from power source before installing or servicing.



**\* NOTICE** Position high current drawing devices nearer to the Feed Terminal, L8-AAT1S.

## 80AMP



## 100AMP

