

<i>Catalogue number</i>	<i>Series ¹</i>	<i>Description</i>
KTE9-40H**-***		IEC Motor Protection Circuit Breakers per Nomenclature
Accessories		
KT9-PE1-10		Front Mount 1 NO Auxiliary Contact
KT9-PE1-11		Front Mount 1 NO 1 NC Auxiliary Contact
KT9-PE1-20		Front Mount 2 NO Auxiliary Contact
KT9-PEF1-S10N10		Front Mount 2 NO Aux Trip Contact
KT9-PEF1-S10N01		Front Mount 1 NC 1 NO Aux Trip Contact
KT9-PEF1-S01N10		Front Mount 1 NO 1 NCAux Trip Contact
KT9-PEF1-S10M10		Front Mount 1 NO Aux Trip Cont. 1 NO SC
KT9-PA1-11		Side Mounted 1 NO 1 NC Auxiliary Contact
KT9-PA1-20		Side Mounted 2 NO Auxiliary Contact
KT9-PA1-02		Side Mounted 2 NC Auxiliary Contact
KT9-AA-24V		Shunt Release Module
KT9-AA-120V		Shunt Release Module
KT9-AA-230V		Shunt Release Module
KT9-AA-260V		Shunt Release Module
KT9-AA-277V		Shunt Release Module
KT9-AA-400V		Shunt Release Module
KT9-AA-480V		Shunt Release Module
KT9-AA-24D		Shunt Release Module
KT9-UA-24V		Undervoltage Release Module
KT9-UA-120V		Undervoltage Release Module
KT9-UA-230V		Undervoltage Release Module
KT9-UA-260V		Undervoltage Release Module
KT9-UA-400V		Undervoltage Release Module
KT9-UA-480V		Undervoltage Release Module
KT9-KN		Blue Lockable Operating Knob
KT9-KRY		Red/Yellow Lockable Operating Knob
KT9-M3		Padlocking Attachment
KT9-HTN		Black Door Coupling Handle
KT9-HTRY		Red/Yellow Door Coupling Handle
KT9-SB		Black Door Coupling Handle
KT9-M3		Padlocking Attachment
KT9-SB		Block Door Coupling Handle
KT9-SY		Red/Yellow Door Coupling Handle
KT9-DNC		Coupler
KT9-N45		Screw Mounting Adapter
KT9-HT		Extension Shaft
KT9-HTS		Extension Shaft Short
KT9-HTL		Extension Shaft Long
KT9-S1		12 Inch Extension Shaft
KT9-S2		21 Inch Extension Shaft
KT9-40-DB-45-2		64A Compact Busbar
KT9-40-DB-45-3		64A Compact Busbar
KT9-40-DB-45-4		64A Compact Busbar
KT9-40-DB-45-5		64A Compact Busbar
KT9-40-DB-54-2		64A Compact Busbar
KT9-40-DB-54-3		64A Compact Busbar
KT9-40-DB-54-4		64A Compact Busbar
KT9-40-DB-54-5		64A Compact Busbar
KT9-40-A3E		80A Feeder Terminal
KT9-40-HA3E		92A Feeder Terminal

1) Les produits du niveau de série indiqué, ainsi que les niveaux de série suivants, sont certifiés. Si aucune lettre ou chiffre de série n'est donné, toutes les séries sont certifiées.

<i>Catalogue number</i>	<i>Series ¹</i>	<i>Description</i>
KT9-40-A2E		Feeder Block
KT9-40-TE		Type E Spacing Adapter
KT9-40-DBA		Compact Bus Bar Terminal Cover
KT9-40-DBA		Compact Bus Bar Terminal Cover
KT9-KBH		Top Hat Rail Adapter
KT9-40-DB-45-2		64A Compact Busbar
KT9-40-DB-45-3		64A Compact Busbar
KT9-40-DB-45-4		64A Compact Busbar
KT9-40-DB-45-5		64A Compact Busbar
KTU9-D-PEC23		32A ECO Connection Module
KT9-40H-PF		40A Flexible Connection Module
KT9-CL		Auxiliary Current limiter
KTE9-OLRF		Auxiliary Device

1) Les produits du niveau de série indiqué, ainsi que les niveaux de série suivants, sont certifiés. Si aucune lettre ou chiffre de série n'est donné, toutes les séries sont certifiées.

MODEL NOMENCLATURE:

IEC Motor Protection Circuit Breakers Catalogue Number Explanation

KTE	9	-	40H	EE	6.3A
I	II		III	IV	V

<i>Position</i>	<i>Catalogue No. Suffix</i>	<i>Options/Descriptions</i>
<i>1</i>	<i>KTE</i>	<i>Base Catalogue Number IEC Motor Protection Circuit Breaker</i>
<i>2</i>	<i>9</i>	<i>Breaking Capacity Type High break</i>
<i>3</i>	<i>40H</i>	<i>Frame Size Frame size D, 40A, with screw terminals, for high breaking capacity</i>
<i>4</i>	<i>EE EF</i>	<i>Protection Type Basic (no communication interface) Advanced (communication interface)</i>
<i>5</i>	<i>1.0A 2.5A 6.3A 16A 40A</i>	<i>Code for Current Range 0.25...1A 0.63...2.5A 1.6...6.3A 4.0...16.0A 10...40A</i>

Accessories Catalogue Number Explanation

A.) Auxiliary Contact Blocks

KT9-PE1-	11
1	2

<i>Position</i>	<i>Catalogue No. Suffix</i>	<i>Options/Descriptions</i>
<i>1</i>	<i>KT9-PE1</i> <i>KT9-PA1</i>	<i>Base Catalogue Number</i> <i>Auxiliary Contact Block front mounted</i> <i>Auxiliary Contact Block side mounted</i>
<i>2</i>	<i>Two digits</i>	<i>Contact Configuration of Auxiliary Contact</i> <i>First digit designates number of N.O. contacts</i> <i>Second digit designates number of N.C. contacts</i>

B.) Trip Contact Blocks Front Mounted

KT9-PEF1	S10	N10
1	2	3

<i>Position</i>	<i>Catalogue No. Suffix</i>	<i>Options/Descriptions</i>
<i>1</i>	<i>KT9-PEF1</i>	<i>Base Catalogue Number of Trip Contact Block Front Mounted</i>
<i>2</i>	<i>S+ two numeric digits</i>	<i>Contact Configuration of Auxiliary Contacts</i> <i>First digit designates the number of N.O contacts. 1 N.C contact, 0 N.O. contact</i> <i>0 N.C. contact, 1 N.O. contact</i>
<i>3</i>	<i>N</i> <i>M</i>	<i>Trip function</i> <i>First contact indicates thermal or magnetic trip</i> <i>Second contact indicates no trip related function</i> <i>First contact indicates thermal or magnetic trip</i> <i>Second contact indicates magnetic trip function</i>
<i>4</i>	<i>Two digits</i>	<i>Contact Configuration of Auxiliary Contacts</i> <i>First digit designates number of N.O. contacts</i> <i>Second digit designates number of N.C. contacts</i>

Accessories Catalogue Number Explanation (continued)

C.) Left Side Mounted Shunt Release Modules

KT9-AA-	24V
1	2

<i>Position</i>	<i>Catalogue No. Suffix</i>	<i>Options/Descriptions</i>
<i>1</i>	<i>KT9-AA-</i>	<i>Base Catalogue Number of Left Side Mounted Shunt Release Module</i>
<i>2</i>	24V 120V 230V 260V 277V 400V 480V 24D	<i>Control Voltage Code (designates voltage and frequency)</i> 24V 50Hz / 24...28V 60Hz 110V 50Hz / 120V 60Hz 220...230V 50Hz 240...260V 60Hz 240V 50Hz / 277V 60Hz 380...400V 50Hz / 440...460V 60Hz 415V 50Hz / 480V 60Hz 24VDC

D.) Undervoltage Release Modules

KT9-UA	120V
1	2

<i>Position</i>	<i>Catalogue No. Suffix</i>	<i>Options/Descriptions</i>
<i>1</i>	<i>KT9-UA</i>	<i>Base Catalogue Number of Undervoltage Release Module</i>
<i>2</i>	24V 120V 230V 260V 400V 480V	<i>Control Voltage Code (designates voltage and frequency)</i> 24V 50Hz / 28V 60Hz 110V 50Hz / 120V 60Hz 220...230V 50Hz 240...260V 60Hz 380...400V 50Hz / 440...460V 60Hz 415V 50Hz / 480V 60Hz

E.) Compact Busbars

KT9-40-DB	45	2
1	2	3

<i>Position</i>	<i>Catalogue No. Suffix</i>	<i>Options/Descriptions</i>
<i>1</i>	<i>KT9-40-DB</i>	<i>Base Catalogue Number of Compact Busbar 64A</i>
<i>2</i>	45 54	<i>Distance between sets of prongs</i> 45 mm 54 mm
<i>3</i>	2 3 4 5	<i>Number of sets of prongs</i> 2 sets of prongs 3 sets of prongs 4 sets of prongs 5 sets of prongs

Accessories Catalogue Number Explanation (continued)

F.) Feeder Terminal

KT9-40-	A3E
1	2

<i>Position</i>	<i>Catalogue No. Suffix</i>	<i>Options/Descriptions</i>
<i>1</i>	<i>KT9-40</i>	<i>Base Catalogue Number</i>
<i>2</i>	<i>A3E</i>	<i>Feeder Terminal 80A</i>

G.) Feeder Block

KT9-40	A2E
1	2

<i>Position</i>	<i>Catalogue No. Suffix</i>	<i>Options/Descriptions</i>
<i>1</i>	<i>KT9-40</i>	<i>Base Catalogue Number</i>
<i>2</i>	<i>A2E</i>	<i>Feeder Block</i>

H.) Current Limiter

KT9	CL
1	2

<i>Position</i>	<i>Catalogue No. Suffix</i>	<i>Options/Descriptions</i>
<i>1</i>	<i>KT9</i>	<i>Base Catalogue Number</i>
<i>2</i>	<i>CL</i>	<i>Current Limiter</i>

I.) Auxiliary Device

KTE9	OLRF
1	2

<i>Position</i>	<i>Catalogue No. Suffix</i>	<i>Options/Descriptions</i>
<i>1</i>	<i>KTE</i>	<i>Base Catalogue Number</i>
<i>2</i>	<i>OLF</i>	<i>Auxiliary Device</i>