

#### Series CATN7 460V AC with Fusible Disconnect (J-Type) ③④

NEMA Size	Max HP 3-Phase ①	Auxiliary Contacts per Contactor ②		Fuse Clip Amps	Type 1 Metallic General Purpose ⑤	Price ⑥	DIM	Type 3R Metallic Outdoor Raintight	Price ⑥	DIM
		NO	NC							
00	0.25	2	1	30	CATN7-12-XC-D1BB-JF61G17-L11	1712	C	CATN7-12-XC-D1BB-JF61R17-L11	2189	0
	0.5	2	1	30	CATN7-12-XC-D1CB-JF61G17-L11	1712	C	CATN7-12-XC-D1CB-JF61R17-L11	2189	0
	0.75	2	1	30	CATN7-12-XC-D1CB-JF61G17-L11	1712	C	CATN7-12-XC-D1CB-JF61R17-L11	2189	0
	1	2	1	30	CATN7-12-XC-D1CB-JF61G17-L11	1712	C	CATN7-12-XC-D1CB-JF61R17-L11	2189	0
	1.5	2	1	30	CATN7-12-XC-D1CB-JF61G17-L11	1712	C	CATN7-12-XC-D1CB-JF61R17-L11	2189	0
	2	2	1	30	CATN7-12-XC-D1CB-JF61G17-L11	1712	C	CATN7-12-XC-D1CB-JF61R17-L11	2189	0
0	3	2	1	30	CATN7-16-XC-D1DB-JF61G17-L11	1755	C	CATN7-16-XC-D1DB-JF61R17-L11	2232	0
	5	2	1	30	CATN7-16-XC-D1DB-JF61G17-L11	1755	C	CATN7-16-XC-D1DB-JF61R17-L11	2232	0
1	7.5	2	1	30	CATN7-37-XC-D1ED-JF61G17-L11	1968	C	CATN7-37-XC-D1ED-JF61R17-L11	2445	0
	10	2	1	30	CATN7-37-XC-D1ED-JF61G17-L11	1968	C	CATN7-37-XC-D1ED-JF61R17-L11	2445	0
2	15	2	1	60	CATN7-43-XC-D1FD-JF62G17-L11	2095	C	CATN7-43-XC-D1FD-JF62R17-L11	2572	0
	20	2	1	60	CATN7-43-XC-D1FD-JF62G17-L11	2095	C	CATN7-43-XC-D1FD-JF62R17-L11	2572	0
	25	2	1	60	CATN7-43-XC-D1FD-JF62G17-L11	2095	C	CATN7-43-XC-D1FD-JF62R17-L11	2572	0
3	30	2	1	60	CATN7-85-XC-EGE-JF62G17-L11	2793	D3	CATN7-85-XC-EGE-JF62R17-L11	3525	0
	40	2	1	100	CATN7-85-XC-EGE-JF63G17-L11	2835	D3	CATN7-85-XC-EGE-JF63R17-L11	3567	0
	50	2	1	100	CATN7-85-XC-EGE-JF63G17-L11	2835	D3	CATN7-85-XC-EGE-JF63R17-L11	3567	0

#### Full Voltage Non-Reversing (FVNR) Features include:

- NEMA-sized CAN7 contactor
- Three-Phase CEP7 Electronic Overload Relay
- Control Circuit Transformer
- Hand-Off-Auto (H-O-A) selector switch
- Red Run pilot light
- 2-NO and 1-NC auxiliaries for customer use
- Class CC Fuse holder as fused primary of CCT
- UL98 fusible L11 disconnect
- Reset pushbutton

#### Series CATN7 575V AC with Fusible Disconnect (J-Type) ③④

NEMA Size	Max HP 3-Phase ①	Auxiliary Contacts per Contactor ②		Fuse Clip Amps	Type 1 Metallic General Purpose ⑤	Price ⑥	DIM	Type 3R Metallic Outdoor Raintight	Price ⑥	DIM
		NO	NC							
00	0.25	2	1	30	CATN7-12-XD-D1BB-JF61G17-L11	1712	C	CATN7-12-XD-D1BB-JF61R17-L11	2189	0
	0.5	2	1	30	CATN7-12-XD-D1CB-JF61G17-L11	1712	C	CATN7-12-XD-D1CB-JF61R17-L11	2189	0
	0.75	2	1	30	CATN7-12-XD-D1CB-JF61G17-L11	1712	C	CATN7-12-XD-D1CB-JF61R17-L11	2189	0
	1	2	1	30	CATN7-12-XD-D1CB-JF61G17-L11	1712	C	CATN7-12-XD-D1CB-JF61R17-L11	2189	0
	2	2	1	30	CATN7-12-XD-D1CB-JF61G17-L11	1712	C	CATN7-12-XD-D1CB-JF61R17-L11	2189	0
	0	3	2	1	30	CATN7-16-XD-D1DB-JF61G17-L11	1755	C	CATN7-16-XD-D1DB-JF61R17-L11	2232
5		2	1	30	CATN7-16-XD-D1DB-JF61G17-L11	1755	C	CATN7-16-XD-D1DB-JF61R17-L11	2232	0
1	7.5	2	1	30	CATN7-37-XD-D1ED-JF61G17-L11	1968	C	CATN7-37-XD-D1ED-JF61R17-L11	2445	0
	10	2	1	30	CATN7-37-XD-D1ED-JF61G17-L11	1968	C	CATN7-37-XD-D1ED-JF61R17-L11	2445	0
2	15	2	1	30	CATN7-43-XD-D1FD-JF61G17-L11	2011	C	CATN7-43-XD-D1FD-JF61R17-L11	2488	0
	20	2	1	60	CATN7-43-XD-D1FD-JF62G17-L11	2095	C	CATN7-43-XD-D1FD-JF62R17-L11	2572	0
	25	2	1	60	CATN7-43-XD-D1FD-JF62G17-L11	2095	C	CATN7-43-XD-D1FD-JF62R17-L11	2572	0
3	30	2	1	60	CATN7-85-XD-EGE-JF62G17-L11	2793	D3	CATN7-85-XD-EGE-JF62R17-L11	3525	0
	40	2	1	60	CATN7-85-XD-EGE-JF62G17-L11	2793	D3	CATN7-85-XD-EGE-JF62R17-L11	3525	0
	50	2	1	100	CATN7-85-XD-EGE-JF63G17-L11	2835	D3	CATN7-85-XD-EGE-JF63R17-L11	3567	0

#### Full Voltage Non-Reversing (FVNR) Features include:

- NEMA-sized CAN7 contactor
- Three-Phase CEP7 Electronic Overload Relay
- Control Circuit Transformer
- Hand-Off-Auto (H-O-A) selector switch
- Red Run pilot light
- 2-NO and 1-NC auxiliaries for customer use
- Class CC Fuse holder as fused primary of CCT
- UL98 fusible L11 disconnect
- Reset pushbutton

① HP and NEMA size selection shown for 460V ratings only. Contact your Sprecher + Schuh representative for other voltage application.

② Contactors are equipped with number and type of auxiliaries indicated. See page C108 to order additional or different auxiliary contacts.

③ Fusible combo starter uses the L11 Disconnect. Fuse clips accept "J" type fuses. Power fuses not supplied.

④ A Red and Yellow Handle may be selected instead of the standard Black handle. Change "JF" to "LF" in catalog number.

⑤ HP and NEMA size selection shown for 575V ratings only. Contact your Sprecher + Schuh representative for other voltage application.

⑥ Dimensional information starts on page C122.

