
MS50 Warning Tower Lights



Assembled Devices



MS50 Warning Tower Lights Assembly Configurator Worksheet

Auer Signal

Ordering Instructions

- 1) Determine the number of levels (up to five) required in the Warning Tower Light
- 2) Choose the Base required (Table A)
- 3) Choose Base & Cap color (Table B) and control voltage (Table C)
- 4) Choose Module Type (Table D) and Lens color (Table E) for up to five levels until the entire catalog number is complete
- 5) Add all List Prices from each table and total your selections.

				Level	One	Level	Two	Level	Three	Level	Four	Level	Five
	A	В	С	D	E	D	E	D	E	D	E	D	Е
WTL50 -	V	G	24	Υ	3	Υ	4	Υ	5	L	7	AS	
					T:	1							

	Table A - Base Type (includes cap) ●				
Catalog Code	Description				
X	Modules only (no base)				
SN	Surface Mount (1/2" NPT Threading)				
SM	Surface Mount (M20 Threading)				
V	Vertical Mount				
L	Pole Mount Base - 5cm [≈2"] aluminum tube w/polycarbonate foot				
L1	Pole Mount Base - 10cm [≈4"] aluminum tube w/polycarbonate foot				
L2	Pole Mount Base - 25cm [≈9-7/8"] aluminum tube w/polycarbonate foot				
L4	Pole Mount Base - 40cm [≈15-3/4"] aluminum tube w/polycarbonate foot				
Q1	Quick Release Pole Mount Base - 10cm [≈4"] aluminum tube w/foot adapter				
Q3	Quick Release Pole Mount Base - 40cm [≈15-3/4"] aluminum tube w/foot adapter				

Table D - Module Type (includes bulb)				
Catalog Code	Description			
D	Steady Incandescent 4			
F	Flashing Incandescent 4			
Υ	Steady LED (VLL + LLL)			
Z	Steady Integrated LED light 5			
L	Flashing LED (VLB + LLL) 2			
В	Strobe - Xenon			
BS	Strobe Integrated LED Single 57			
S	Strobe Integrated LED Multi 🗗			
AS	Sound - single circuit, dual tone 3			
AD	Sound - dual circuit, dual tone 🔇			

Gray de	notes s	pecial	order
---------	---------	--------	-------

Table B - Base & Cap Color				
Catalog Code	Description			
В	Black			
G	Gray			

Table C - Voltage				
Catalog Code	Description			
12	12V AC/DC Full Voltage			
24	24V AC/DC Full Voltage			
120	120V AC Full Voltage			
240	240V AC Full Voltage			



Download the **Configurator** Worksheet

Table E - Lens Color 🗿				
Catalog Code	Description			
3	Green			
4	Red			
5	Amber			
6	Blue			
7	Clear			
8	Yellow			

- For a Pole Mount Base with Junction Box, order desired Pole Mount from this table and field install Junction Box as an accessory.
- 2 Assembled as a Flashing Module with Steady LED bulb (LLL).
- 3 Sound Modules must be installed as the last component (top level) of the tower light assembly. If selecting Dual Tone Sound Modules a maximum of four modules, consisting of three Light Modules and one Dual Sound Module, is possible.
- 4 Assembly includes incandescent bulbs.
- Not available in 12V AC/DC, 120V AC.
- 6 Lens color codes for assembled towers do not correspond with color codes for ordering individual beacon modules as components. Some modules have limited colors and voltages. See component pages for details.
- Only available in Red and Amber.

15910 International Plaza Dr., Houston, TX 77032 Customer Service: (877) 721-5913 Canada: (800) 343-0464

